

Quick Features Guide

Payment

Enter machine number or scan QR code to select an available machine.

Load laundry and then tap **Pay**.


Depending on your machine type, you will either select your fabric setting or push the start button on the machine.



Request Service

Tap on the **Support** icon and then select **Machine Not Working**.


Simply scan the barcode displayed on the machine or enter the six-digit machine ID.



Refund Request

Tap on the **Support** icon and select **Request a Refund** to see your transaction history.

Tap on the transaction you'd like a refund for, fill in the required fields, and tap submit.



Resources

Tap on **More** and select **Resources** to access our robust section of helpful laundry tips!

